

SEC|DEC

SETTINGS GUIDE

WINDOWS

DISPLAY SETTINGS

- Select Start > Settings > System > Display
- To change your screen resolution, use the drop-down menu next to Display resolution.

DISPLAY ARRANGEMENT

- Select Start > Settings > System > Display
- Under the "Select and rearrange displays" section, click the Identify button to determine which displays you'll be arranging.
- Click, drag, and drop each display to arrange them according to their physical layout on the desk. Select "extend display".

TOUCH SCREEN

- Touch screen functionality will work natively in windows as a mouse/ pointer device. No driver installation is required
- *Touch functionality can also be used in tablet mode.

MAC

DISPLAY SETTINGS

- System Settings > Displays
- To change your screen resolution, use "larger text" to "more space" preset range -or- click "advanced" button to manually select resolution.

DISPLAY ARRANGEMENT

- System Settings> Displays> Arrange (button)
- Click, drag, and drop each display to arrange them according to their physical layout on the desk. Select "extend display".

TOUCH SCREEN

- Visit www.sec-dec.com for driver and installation instructions.